

NCR POS Integration

LaneHawk is available as part of NCR's POS solutions. All ACS releases 6.2 and above now include the LaneHawk module.

How LaneHawk Works


- BOB items are identified and added to the POS transaction in real time, thus capturing the losses as they occur – not after the unpaid-for products leave the store.
- Cashier activities are recorded in the POS Tlog, allowing you to track and document checkout activities by criteria such as cashier or lane.
- A report of all accepted and cleared BOB items is created to ensure cashier compliance with Store Operating Procedures.

Store Integration


- The LaneHawk/NCR POS integration is available with multiple options, which can be turned on or off for a customer's specific front-end environment.
- A LaneHawk device is installed in each lane and connected to a back-office server.
- The back-office server processes item images and data.



To find out more about LaneHawk, go to www.evoretail.com



Example of NCR ACS Dynakey POS system showing LaneHawk item recognition



Example of how LaneHawk is integrated in a store's architecture

To learn more about product details, purchasing information or for a demonstration, please contact us at:



www.ncbpinc.com

P.O. Box 910
Bemidji, MN 56619-0910
(888) 505-0540
info@ncbpinc.com